




Dimension:




2-Way Coaxial Ceiling Speaker


Installation Steps:




① Cut Ceiling Hole



② Connect Wiring



③ Tighten the fastening screws in a clockwise direction.



④ Attach the grille.



TCI-308F

User's Manual

Dear customers:

Your use of the TCI speaker series, we would like to extend my heartfelt thanks to you, the commitment to keep its quality.

Our speakers are widely used for hotels, commercial buildings, supermarkets, schools, leisure and entertainment venues, is your ideal choice.

For your installation, commissioning and use of this product, the installation please read this note.

Safety Tips

- Please be sure to use the former reading detailed notes.
- Really pay attention to this manual and a safety with the important warning.
- Recommend that you keep this manual for future reference.

Common warning signs and security

The manual shown warning signs and security is to prevent the improper operation due to personal injury arising from the loss of property, please read before using this product must understand that this manual security symbols and Warning to indicate fully aware of potential risks.

	<p>Warning Such as the inappropriate use of staff will cause injury, death and property damage.</p>
--	--

When installed loudspeakers

- Definitely will not be allowed to speakers and any exposure in the rain-wet or water, may be inconsistent with , or fire.
- Restricted by the provisions of the speakers on the voltage, such as the us of high voltage may cause electric shock or fire disaster. Is no pruning, distorted, or replacement of damaged wires.
- Avoid instability in the installation or set up speakers, such as shaking the table or flat surface , the speaker can avoid falling caused personal injury or property damage.
- Speakers will be installed in support of the speaker or the weight of a solid shelf. Speaker swap can be avoided caused personal injury or property damage.
- Wet hands must not be admitted into or plugs, may lead to electric shocks.
- The allocation of plugs, make sure that pull plugs, rather than pull wires.
The use of a damaged power line of machinery may cause fire or electric shock.
- Mobile speaker, you plug the prior allocated. If the speaker and plugs may be moving together will cause fire or electric shock. For plugs, identified as plugs for grip.
- Will not be allowed to speakers on the vent cover, may cause internal heating caused by the fire.
- Avoid speakers installed in the humidity or dust, direct contact with the sun from the near-electric, or smoke or steam, may cause fire or electric shock

Features:

- ※ Rimless design with magnetically-attached grille.
- ※ 2-way coaxial sound system with professional crossover.
- ※ 6.5" woven cone woofer.
- ※ 1" silk dome tweeter.
- ※ 100V or 70V distributed speaker lines, or in 8 ohm direct mode.
- ※ Adjustable knob to select input mode and various power outputs .
- ※ Attractive color ABS resin finish with white grille suits any decor.

Specifications:

Model	TCI-308F		
Input Mode	70V	100V	8 Ω
Power Taps	2=1.88W 3=3.75W 4=7.5W 5=15W 6=30W	2=3.75W 3=7.5W 4=15W 5=30W 6=N.C.	1=30W
<p>● DO NOT USE IN POSITION 1(8Ω) ON A 70V/100V SYSTEM, OR DAMAGE WILL OCCUR. ● DO NOT USE IN POSITION 6(N.C.) ON A 100V SYSTEM, OR DAMAGE WILL OCCUR.</p>			
SPL(1W/1M)	90 dB		
Freq. Response	70-20KHz		
Woofer Driver	woven cone 6.5"*1		
Tweeter Driver	silk dome 1"*1		
Material	ABS enclosure, metal grille and clamps		
Cutout Size	Φ205mm		
Dimension	Φ235*101mm		
Finish	White		